
SIDE STAND

Refer to Maintenance Precautions on page 64.

Check the side stand system for proper function.

- Check the spring for damage or loss of tension and the side stand assembly for freedom of movement.

- Check the side stand ignition cut-off system:

1. Sit astride the motorcycle; put the side stand up and the transmission in neutral.
2. Start the engine and with the clutch lever pulled in, shift the transmission into gear.
3. Move the side stand fully down. Lower the side stand.

The engine should stop as you put the side stand down.

If the side stand system does not operate as described, see your authorized Honda dealer for service.

