

Removal

1. **CRF1100A/D**
Remove the bolts A and washers. using the hex wrench provided on the underside of the rear seat. 2 P. 253
2. **CRF1100A4/D4**
Remove the bolt B, bolts A and washers. using the hex wrench provided on the underside of the rear seat. 2 P. 253
3. Remove the collar.
4. Remove the skid plate by releasing its grommet from the prong.

Installation

1. Install the skid plate in the reverse order of removal.
2. Install the collar.
3. Install the washers onto the bolts A.
4. Tighten the bolts A.

Torque: 19 lbf·ft (26 N·m, 2.7 kgf·m).

5. **CRF1100A4/D4**
Install the washer onto the bolt B and tighten the bolt B.

Torque: 9 lbf·ft (12 N·m, 1.2 kgf·m).