

INSTALLATION

Route the side stand switch wire properly (page 1-24).

Install the side stand switch by aligning the switch pin with the side stand hole and switch groove with the return spring holding pin.

Secure the side stand switch with a new bolt.

TORQUE: 9.8 N-m (1.0 kgf-m, 7 lbf-ft)

Connect the side stand switch 2P (Green) connector. Install the 2P (Green) connector into the connector boot with regulator/rectifier 2P connector.

Bundle the connector boots in the wire band. Install the middle and under cowls (page 3-9).

