

## FRAME/BODY PANELS/EXHAUST SYSTEM

Install the mufflers.  
Temporarily install the muffler mounting bolt/nut.

Install the main footpeg holders and tighten the mounting bolts.

**TORQUE:** 26 N·m (2.7 kgf·m , 20 lbf·ft)

Tighten the muffler bracket cap nut to the specified torque.

**TORQUE:** 26 N·m (2.7 kgf·m , 20 lbf·ft)

Tighten the muffler mounting bolt/nut to the specified torque.

**TORQUE:** 26 N·m (2.7 kgf·m , 20 lbf·ft)

Tighten the muffler clamp bolts alternately, then tighten to the specified torque.

**TORQUE:** 17 N·m (1.7 kgf·m , 12 lbf·ft)

Install the lower cowl (page 2-4).

