


Odometer/Tripmeter/Coolant temperature meter (display mode 1)

The Display mode 1 has three functions: odometer, tripmeter and coolant temperature.

Press the left control button (1) to select “ODO” (Odometer), “TRIP 1” (Tripmeter 1), “TRIP 2” (Tripmeter 2) and “TEMP” (Coolant temperature) mode.

ED/F/U model: Odometer and tripmeter read in kilometers.

E model: Odometer and tripmeter read in miles.



(1) Left control button

