


Digital Clock

The digital clock will show hours and minutes up to 12:59 with "AM" and "PM".

To adjust the time, proceed as follows:

1. Turn the ignition switch ON.
2. Press and hold the right control button (1) for more than 2 seconds. The clock will be set in the adjust mode with the hour flashing.
 - When TODAY present date or Stopwatch is displayed, adjust mode can not be selected.



- (1) Right control button
(2) Left control button



3. To set the hour, press the right control button until the desired hour and AM/PM are displayed.
 - Quick setting – press and hold the right control button until the desired hour appears.
4. Press the left control button (2) when the display reaches the desired hour. The minute display will be flashing.

