

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								
			× 1,000 km	1	6	12	18	24	30	36	Refer to Page
			× 1,000 mi	0.6	4	8	12	16	20	24	
MONTH	6	12	18	24	30	36					
* FUEL LINE					I		I		I		—
* THROTTLE OPERATION					I		I		I		127
AIR CLEANER		NOTE (2)					I		I		129
SPARK PLUGS					I		R		I		124
* VALVE CLEARANCE							I				—
ENGINE OIL			R		R		R		R		115
ENGINE OIL FILTER			R		R		R		R		119
CRANKCASE BREATHER		NOTE (3)		I	I	I	I	I	I		122
RADIATOR COOLANT		NOTE (4)			I		I		R		57
* COOLING SYSTEM					I		I		I		—
* SECONDARY AIR SUPPLY SYSTEM					I		I		I		—