

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
DRIVE CHAIN			I, L EVERY 1,000 km (600 mi)								130
DRIVE CHAIN SLIDER					I		I		I	137	
BRAKE FLUID		NOTE (4)		I	I	R	I	I	R	52	
BRAKE PAD WEAR				I	I	I	I	I	I	146	
BRAKE SYSTEM			I		I		I		I	52	
* BRAKE LIGHT SWITCH					I		I		I	—	
* HEADLIGHT AIM					I		I		I	—	
CLUTCH SYSTEM					I		I		I	55	
CLUTCH FLUID		NOTE (4)		I	I	R	I	I	R	55	
SIDE STAND					I		I		I	139	
* SUSPENSION					I		I		I	138	
* NUTS, BOLTS, FASTENERS			I		I		I		I	—	
** WHEELS/TYRES					I		I		I	—	
** STEERING HEAD BEARINGS			I		I		I		I	—	