


Brake/Tail Light

Brake and taillight use some LED.
If there is a LED which is not turned on, see
your Honda dealer for this service.



(1) Brake/tail light