

ITEMS	FREQUENCY	WHICHEVER → COMES		ODOMETER READING [NOTE (1)]								Refer to pages
		FIRST	x 1,000 km	1	6	12	18	24	30	36		
		↓	x 1,000 mi	0.6	4	8	12	16	20	24		
	NOTE	MONTH		6	12	18	24	30	36			
	DRIVE CHAIN			EVERY 1,000 km (600 mi) I, L								60
	DRIVE CHAIN SLIDER				I			I		I	65	
	BATTERY				I	I	I	I	I	I	76	
	BRAKE FLUID	NOTE (5)			I	I	R	I	I	R	13	
	BRAKE PAD WEAR				I	I	I	I	I	I	74	
	BRAKE SYSTEM			I		I		I		I	13,74	
*	BRAKE LIGHT SWITCH					I		I		I	—	
*	HEADLIGHT AIM					I		I		I	—	
	CLUTCH SYSTEM			I	I	I	I	I	I	I	17	
	SIDE STAND					I		I		I	66	
*	SUSPENSION					I		I		I	—	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—	
**	WHEELS/TYRES					I		I		I	—	
**	STEERING HEAD BEARINGS			I		I		I		I	—	