

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page	
			× 1,000 km	1	6	12	18	24	30	36		
			× 1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
	DRIVE CHAIN			I, L EVERY 1,000 km (600 mi)								97
	DRIVE CHAIN SLIDER					I		I		I	103	
	BRAKE FLUID	NOTE (4)			I	I	R	I	I	R	27	
	BRAKE PAD WEAR				I	I	I	I	I	I	112	
	BRAKE SYSTEM			I		I		I		I	27, 112	
*	BRAKE LIGHT SWITCH					I		I		I	—	
*	HEADLIGHT AIM					I		I		I	—	
	CLUTCH SYSTEM			I	I	I	I	I	I	I	30	
	SIDE STAND					I		I		I	105	
*	SUSPENSION					I		I		I	104	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—	
**	WHEELS/TYRES					I		I		I	—	
**	STEERING HEAD BEARINGS			I		I		I		I	—	