

Check the tyres for cuts, embedded nails or other sharp objects. Check the rims for dents or deformation. If there is any damage, see your authorized Honda dealer for repair, replacement, and balancing.

**▲ WARNING**

- \* **Improper tyre inflation will cause abnormal tread wear and create a safety hazard. Underinflation may result in the tyre slipping on, or coming off of the rim causing tyre deflation that may result in a loss of vehicle control.**
- \* **Operation with excessively worn tyres is hazardous and will adversely affect traction and handling.**

Replace tyres before tread depth at the center of the tyre reaches the following limit:

<b>Minimum tread depth</b>	
<b>Front :</b>	<b>1.5 mm (0.06 in)</b>
<b>Rear :</b>	<b>2.0 mm (0.08 in)</b>

**NOTE:** <For Germany>

- \* German law prohibits use of tyres whose tread depth is less than 1.6 mm.