

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓ NOTE	ODOMETER READING [NOTE(1)]								REFER TO PAGE
			x 1,000 km	1	6	12	18	24	30	36	
			x 1,000 mi	0.6	4	8	12	16	20	24	
DRIVE CHAIN			I, L, EVERY 1,000 km (600 mi)								74-78
DRIVE CHAIN SLIDER					I		I		I		79
BATTERY					I		I		I		92-94
BRAKE FLUID		(NOTE 4)			I		I	R	I		17-20
BRAKE PAD WEAR					I		I		I		89
BRAKE SYSTEM					I				I		17-20, 91
* BRAKE LIGHT SWITCH							I		I		97
* HEADLIGHT AIM							I		I		-
CLUTCH SYSTEM							I		I		21
CLUTCH FLUID		(NOTE 4)			I		I	R	I		21
SIDE STAND							I		I		80
* SUSPENSION							I		I		79
* NUTS, BOLTS, FASTENERS					I				I		-
** WHEELS/TYRES							I		I		-
** STEERING HEAD BEARINGS					I				I		-