## **BULB REPLACEMENT**

(Refer to the maintenance precautions on page 61).

Headlight/Position Light Bulb

## **AW** ARNING

\* The light bulb becomes very hot while the light is ON, and remain hot for a while after it is turned OFF. Be sure to let it cool down before servicing.

## CAUTION:

- \* Wear clean gloves while replacing the bulb.
- \* Do not put finger prints on the headlight bulb, as they may create hot spots on the bulb and cause it to break.
- \* If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol to prevent its early failure.

## NOTE:

\* Be sure to turn the ignition switch OFF when replacing the bulb.