

Starting Procedure

This motorcycle has an automatic choke.
Follow the procedure indicated below.

Any Air Temperature

- Press the starter button with the throttle completely closed.

NOTE:

- * Do not open the throttle fully when starting the engine.

CAUTION:

- * **The red low oil pressure indicator should go off a few seconds after the engine starts. If the light stays on, stop the engine immediately and check engine oil level. Operating the engine with insufficient oil pressure can cause serious engine damage.**