

You will need the key number if you ever have to replace a key. Store the plate in a safe place.

< Except MX, BR type >

To reproduce keys, bring all keys, key number plate and motorcycle to your Honda dealer.

Up to four keys can be registered with the immobilizer system (HISS), including the ones in hand.

NOTE: < Except MX, BR type >

- * If all keys are lost, the PGM-FI unit/ignition control module must be replaced. To avoid this possibility we recommend that if only one key is left, you immediately have it reproduced to ensure that a back-up is available.
- * These keys contain electronic circuits that are activated by the immobilizer system (HISS). They will not work to start the engine if the circuits are damaged.
 - Do not drop the keys or set heavy objects on them.
 - Do not grind, drill or in any way alter the original shape of the keys.
 - Keep the keys away from magnetic objects.