

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	×1,000 km	1	6	12	18	24	30	36	Refer to pages
			×1,000 mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
DRIVE CHAIN			EVERY 1,000 km (600 mi) L, L								89
DRIVE CHAIN SLIDER					I			I		I	95
BRAKE FLUID	NOTE (3)			I	I	R		I	I	R	30
BRAKE PAD WEAR				I	I	I		I	I	I	103
BRAKE SYSTEM			I		I			I		I	30, 103
* BRAKE LIGHT SWITCH					I			I		I	—
* HEADLIGHT AIM					I			I		I	—
CLUTCH SYSTEM			I	I	I	I		I	I	I	34
** EXHAUST VALVE CONTROL CABLE								I			—
SIDE STAND					I			I		I	97
* SUSPENSION					I			I		I	96
* NUTS, BOLTS, FASTENERS			I		I			I		I	—
** WHEELS/ TYRES					I			I		I	—
** STEERING HEAD BEARINGS			I		I			I		I	—