

Servicing Your Honda

Service Preparations

Maintenance Component Locations	52
Tools.....	55
Side Cover Removal	56

Service Procedures

Fluids & Filters

Fuel.....	57
Engine Oil	60
Air Cleaner	66

Engine

Throttle.....	69
Clutch System	71
Engine Idle Speed	75
Spark Plug	76
Spark Arrester	78

Chassis

Suspension	80
Brakes.....	83
Wheels.....	89
Tires & Tubes.....	94
Side Stand	98
Drive Chain	99

Appearance Care	106
-----------------------	-----