






Refer to the Safety Precautions on page 55.

Brake pad wear depends upon the severity of usage, the type of riding, and road conditions. (Generally, the pads will wear faster on wet and dirty roads.)
Inspect the pads at each regular maintenance interval (page 56).



Check the wear limit groove (1) in each pad. If either pad is worn to the groove, replace both pads as a set. See your dealer for this service.

## ⟨FRONT BRAKE⟩





(1) Wear limit grooves

