Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine, turn the engine stop switch to \bigotimes (OFF) and push the choke lever down to Fully OFF (B). Open the throttle fully and crank the engine several times with the kickstarter. Turn the engine stop switch to \bigcap (RUN) and open the throttle slightly; start the engine using the kickstarter.

RUNNING-IN

Help assure your motorcycle's future reliability and performance by paying extra attention to how you ride during the first operating day or 25 km (15 miles).

During this period, avoid full-throttle starts and rapid acceleration.