

ITEM		FREQUENCY	WHICHEVER COMES FIRST ↓ NOTE	ODOMETER READING [NOTE(1)]								REFER TO PAGE
				× 1,000 km	1	6	12	18	24	30	36	
				× 1,000 mi	0.6	4	8	12	16	20	24	
				6	12	18	24	30	36			
*	DRIVE BELT					I	R	I	I	R	—	
	BELT CASE AIR CLEANER				C	C	C	C	C	C	69	
*	FINAL DRIVE OIL	(NOTE 5)									—	
	BRAKE FLUID	(NOTE 4)			I	I	R	I	I	R	18	
	BRAKE SHOE/PAD WEAR				I	I	I	I	I	I	80, 81	
	BRAKE SYSTEM			I		I		I		I	18, 80, 81	
*	BRAKE LIGHT SWITCH					I		I		I	—	
*	STARTER LIMIT SWITCH					I	I	I	I	I	—	
*	BRAKE LOCK OPERATION			I	I	I	I	I	I	I	38	
*	HEADLIGHT AIM					I		I		I	—	
**	CLUTCH SHOE WEAR					I	I	I	I	I	—	
	SIDE STAND						I	I		I	79	
*	SUSPENSION						I	I		I	—	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—	
**	WHEELS/TYRES					I		I		I	—	
**	STEERING HEAD BEARINGS			I		I		I		I	—	