

The opening/ending ceremony can be turned off.

1. Push the MODE button to cycle to the “OPENING/ENDING CEREMONY” screen.
2. Push the DISP. button to cycle between on/off of the display.
3. Push the MODE button to select the “SET” function.
Selecting the “SET” function locks in the on/off option for future use.

ceremony display ON



ceremony display OFF

