

ITEM	FREQUENCY	WHICHEVER →		ODOMETER READING [NOTE (2)]				Refer to pages
		COMES FIRST ↓	x 1,000 km	1	4	8	12	
			x 1,000 mi	0.6	2.5	5	7.5	
NOTE		MONTH		6	12	18		
* FINAL DRIVE OIL		2 YEARS R						—
BATTERY					I	I	I	49–50
BRAKE SHOE WEAR					I	I	I	48
BRAKE SYSTEM				I	I	I	I	12–13
* BRAKE LIGHT SWITCH					I	I	I	—
* HEADLIGHT AIM					I	I	I	—
* SUSPENSION					I	I	I	—
* NUTS, BOLTS, FASTENERS				I		I		—
** CLUTCH SHOE WEAR						I		—
** WHEEL/TYRES					I	I	I	—
** STEERING HEAD BEARINGS				I			I	—

* SHOULD BE SERVICED BY YOUR AUTHORIZED HONDA DEALER UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SERVICE MANUAL.

** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY YOUR AUTHORIZED HONDA DEALER.

NOTE: (1) Service more frequently when riding in dusty areas.

(2) For higher odometer readings, repeat at the frequency interval established here.