

Refueling

Fuel type: Unleaded gasoline only

Recommended fuel octane number:


Pump Octane Number (PON) 86 or higher.

Tank capacity: 1.32 US gal (5.0 liters)

Refueling and Fuel Guidelines P.12

Opening the Fuel Fill Cap

- 1 Pull the tab and open the fuel tank lid.
- 2 Insert the ignition key in the fuel fill cap and turn it clockwise until it stops.
- 3 Turn the fuel fill cap counterclockwise until it stops and remove the cap.



Do not fill with fuel above the lower edge of the filler neck.