



Speed and Mileage Unit Change

< E type only >

The speedometer displays both "km/h" and "mph".

The odometer/tripmeter displays both "km" and "mile".

Push and hold the RESET button (1) for more than 2 seconds to select "km/h"/"km" or "mph"/"mile" with the odometer display selected.



(1) RESET button