



To switch the transmission into D mode:

Press and hold the D (drive) side (2) of the N-D shift switch until the neutral indicator (3) turns off and the D mode indicator (4) comes on.



- (1) N-D shift switch
- (2) N-D shift switch (D)

- (3) Neutral indicator
- (4) D mode indicator