

## **OPERATION**

### **PRE-RIDE INSPECTION**

For your safety, it is very important to take a few moments before each ride to walk around your motorcycle and check its condition. If you detect any problem, be sure you take care of it, or have it corrected by your Honda dealer.

### **⚠ WARNING**

Improperly maintaining this motorcycle or failing to correct a problem before riding can cause a crash in which you can be seriously hurt or killed.

Always perform a pre-ride inspection before every ride and correct any problems.

1. Engine oil level—add engine oil if required (page 40). Check for leaks.
2. Fuel level—fill fuel tank when necessary (page 37). Check for leaks.
3. Coolant level—add coolant if required. Check for leaks (pages 35 – 36).
4. Front and rear brakes—check operation; make sure there is no brake fluid leakage (pages 32 – 34).