
If you cannot restart a warm engine:

1. Place the scooter on its center stand and set the rear brake lock.

2. Rotate the throttle (1) 1/8-1/4 turn while starting the engine.



(1) Throttle