


### Rear Turn Signal Bulb

1. Remove the turn signal lens (1) by removing the screws (2).
2. Remove the taillight lens (3) and turn signal lens (1).
3. Remove the bulb (4) by pressing in and turning counterclockwise.
4. Install a new bulb in the reverse order of removal.



- (1) Turn signal lens
- (2) Screws
- (3) Taillight lens
- (4) Bulb