


FEATURES (Not required for operation)

REAR VIEW MIRROR COVERS

Both rear view mirror covers use a special breakaway mount which allows a controlled separation of the mirror covers from its base upon impact with an obstacle. A short cable keeps the mirror covers connected to the mirror bracket.

Installation:

- Check the mirror for correct angle.
- Press on the mirror covers firmly until they click into position on the mirror mounts.
- After reinstalling, check the mirror for connect angle and the front turn signals for proper operation.



CAUTION:

- ***Riding with a mirror cover hanging by its retaining cable may damage the motorcycle's plastic body.***

NOTE:

- For your safety, be sure to immediately reassemble any separated mirror cover. Otherwise, the mirror and turnsignal will not be available to you while riding.

If a mirror cover is damaged so badly that it cannot be reused or reinstalled on its base, remove it from the base and transport the motorcycle to an authorized Honda dealer.