



Gear Change Pedal : The gear change pedal ① located near the left foot rest is of the progressive shift, positive stop type, which means one full stroke of the gear change pedal will shift only one gear position.



① Gear change pedal

The shifting sequence is arranged as shown in the figure.



Gear change sequence

Shifting to low gear from neutral is performed by depressing the rear end of the gear change pedal; shifting into second and top gears are made by depressing the forward end of the pedal in sequence.

Shifting down in gear is accomplished by depressing the rear end of the gear change pedal in successive sequence.