

Service Required	Months or Miles, whichever occurs first					Page Reference	
	Month	First	Second	Third	Thereafter Repeat Every		
		—	6	12	6		12
		Mile	200	3,000	6,000		3,000
Km	300	5,000	10,000	5,000	10,000		
*Engine Oil-change	<input type="radio"/>	Every 1,000 Miles (1,600 km)				41	
*Spark Plug-clean and adjust or replace		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		55	
*Contact Breaker Points-check or service		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		43	
Ignition Timing-check or adjust	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		43	
Valve Tappet Clearance-check or adjust	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		45	
*Air Cleaner-clean and		<input type="radio"/>			<input type="radio"/>	52	
replace			<input type="radio"/>		<input type="radio"/>	52	
Throttle Operation-check		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		60	
Carburetor-check or adjust		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		60	
*Fuel Valve Strainer-clean		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		61	
*Fuel Tank and Fuel Lines-check		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		23	
Clutch-check or adjust	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		43	

* denotes service the owner may perform.