


TOOL

The tool kit ① is contained in the compartment located under the seat. Minor adjustment and parts replacement can be performed with the tools contained in the kit. Adjustments or repairs which cannot be performed with the tools in the kit should be referred to your HONDA dealer.



① Tool kit

Listed below are the items included in the tool kit

- Spark plug wrench: for spark plug, front and rear axle nut
- 14×17 mm open end wrench
- 10×12 mm open end wrench
- 9 mm spanner
- Pliers
- No. 3 screw driver
- No. 2 cross point screw driver
- No. 1 cross point screw driver
- 8 mm spanner: for valve tappet clearance adjustment, screw driver
- Screw driver grip: for screw driver
- Valve tappet adjust wrench: for valve tappet clearance adjustment
- Tool bag

Items attached to the motorcycle in a separate package

- A cap of touch-up paint
- Spare battery fuse