

L

Loading	
Loading guidelines and procedures.....	40
Weight limits.....	39
Lubrication	
(see Engine oil, Gear case oil)	

M

Maintenance	
Precautions.....	84
Schedule.....	82
Modifications.....	44

N

Neutral indicator lamp.....	22
Noise emission control system.....	146

O

Obstacles, riding over.....	78
Oil (see Engine oil, Gear case oil)	
Oil filler cap/dipstick.....	28
Oil filter, changing.....	102
Owner's manual compartment.....	31

P

Parking.....	80
Parts location.....	10
Parking brake.....	25
Passenger carrying.....	46
Pavement, no riding on.....	48
Pinging.....	88
Power supply, 12V DC.....	32
Pre-ride inspection.....	36

R

Reverse	
Assist cable.....	109
Assist lever.....	109
Gear, shifting into.....	24, 61