

# Controls & Features


---

## Gearshift Switch

These switches are used to select the next higher or lower gear in the transmission. To operate, press the upshift switch ( 1 ) to engage the next higher gear or press the downshift switch ( 2 ) to engage the next lower gear.

See *Shifting Gears*, page 65 .

### LEFT HANDLEBAR



- (1) upshift switch
- (2) downshift switch