


Controls & Features

Start Button (TRX450ER only)



LEFT HANDLEBAR



(1) start button

(3) START

The start button (1) is used for starting the engine. Pushing the button in starts the engine. See *Starting Procedure*, page 50 .

When the start button is pushed, the starter motor will crank the engine. The starter motor will operate even if the engine stop switch is in the OFF (⊗) position when the start button is pushed.