


Controls & Features

Drive Mode Select Switch

The drive mode select switch (1) has three positions, D1, D2, and ESP. See *Shifting Gears* page 72 .

LEFT SIDE OF HANDLE COVER



(1) drive mode select switch