

GPScape System (TRX500FGA only)

This section explains the GPScape navigation system. Instructions for the topics listed on this page are included.

Introduction.....	48
Important Safety Information	51
System Limitations.....	52
System Start-up.....	53
Position Fix	53
System Failure to Display a Position Fix	54
Satellite Status	56
GPS Mode.....	58
GPS Mode Display.....	60
Waypoint Number Display	61
Direction to Waypoint Display	62
Distance to Waypoint	64
Basic Waypoint Selection	65
Advanced Waypoint Selection	67
Determining the Coordinates of Your Current Position.....	71
Compass Direction Indicator.....	72
Automatic Clock Adjustment.....	74