

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE	
			x 1,000 km	1	6	12	18	24	30	36		
			x 1,000 mi	0.6	4	8	12	16	20	24		
											EVERY 1,000 km (600 mi) I, L	72-75
						I		I			I	76
		(NOTE 3)			I	I	R	I	I	R		19-22
					I	I	I	I	I	I		85
					I		I		I	I		19-22
*						I		I		I		96
*							I		I		I	-
							I		I		I	23-24
							I		I		I	-
		(NOTE 3)			I	I	R	I	I	R		-
*							I		I		I	-
*					I		I		I		I	-
**							I		I		I	-
**					I		I		I		I	-