

FREQUENCY		WHICHEVER →		ODOMETER READING [NOTE(1)]								REFER TO PAGE
				COMES FIRST ↓	x 1,000 km	1	6	12	18	24	30	
ITEM	NOTE	x 1,000 mi	0.6	4	8	12	16	20	24			
		MONTH		6	12	18	24	30	36			
DRIVE CHAIN			I, L, EVERY 1,000 km (600 mi)								86-90	
DRIVE CHAIN SLIDER					I		I		I		91	
BRAKE FLUID	(NOTE 3)			I	I	R	I	I	R		23-26	
BRAKE PAD WEAR				I	I	I	I	I	I		102	
BRAKE SYSTEM			I		I		I		I		23-26, 103	
* BRAKE LIGHT SWITCH					I		I		I		109	
* HEADLIGHT AIM					I		I		I		-	
CLUTCH SYSTEM					I		I		I		27	
CLUTCH FLUID	(NOTE 3)			I	I	R	I	I	R		27	
SIDE STAND					I		I		I		103	
* SUSPENSION					I		I		I		92	
* NUTS, BOLTS, FASTENERS			I		I		I		I		-	
** WHEELS/TYRES					I		I		I		-	
** STEERING HEAD BEARINGS			I		I		I		I		-	