

(Ref.No.) Description	Function
(1) Speedometer	Shows riding speed.
(2) Left turn signal indicator (green)	Flashes when the left turn signal operates.
(3) Tachometer	Shows engine rpm.
(4) Tachometer red zone	<p>Never allow the tachometer needle to enter the red zone, even after the engine has been broken in.</p> <p>CAUTION:</p> <p>* Running the engine beyond recommended maximum engine speed (the beginning of the tachometer red zone) can damage the engine.</p>
(5) Right turn signal indicator (green)	Flashes when the right turn signal operates.