



### Digital clock

Shows hour and minute. To adjust time, proceed as follows :

1. Turn the ignition switch ON.
2. Press and hold the TEMP (1) and TRIP (2) button for more then 2 seconds. The display will be set mode.
3. Press the TEMP button (1). To advance time, keep the button down until the desired hour is displayed.
4. Press the TRIP button (2). To advance, hold the button down. The display will be returned to "00" when "60" minutes are reached without affecting the hour display.



- (1) TEMP button
- (2) TRIP button