

Instruments *(Continued)*

The average fuel mileage and fuel consumption will be based on each tripmeter A and tripmeter B.

Average fuel mileage

Average fuel mileage since each tripmeter A and tripmeter B was reset. It display "--:--" after resetting each tripmeter A and tripmeter B.

When "--:--" is displayed in other cases, go to your dealer for service.

Fuel consumption

Total fuel consumption since each tripmeter A and tripmeter B was reset. When "--:--" is displayed, go to your dealer for service.

To reset the average fuel mileage and fuel consumption:  **P.22**

Current fuel mileage

Current instant mileage. If your speed is less than 4 mph (7 km/h) or immediately after ignition switch is turned to ON, "--:--" is displayed.

When "--:--" is displayed at speeds above 4 mph (7 km/h), go to your dealer for service.