

Gauges, Indicators & Displays

12	odometer/tripmeter display	The display includes the following functions: <i>Display Check.</i>
	odometer	Shows the total miles or kilometers ridden (page 35).
	tripmeter A & B	Shows the number of miles or kilometers ridden since you last reset the meter. The tripmeter has two sub modes, “A” and “B.” To zero (0) the tripmeter, push and hold control button A (pages 35 – 36).
	fuel mileage meter	Shows current fuel mileage, average fuel mileage, or fuel consumption. See pages 37 – 39 . When the low fuel indicator comes on, the display is changed to the reserve fuel consumption (page 28).