

Taking Care of the Unexpected

This section discusses the more common problems that can occur with your motorcycle while you're riding. It tells you how to evaluate each problem and what actions you can take to try to resume riding. If the problem cannot be safely solved, this section also gives instructions on the proper way to have your motorcycle transported.

For information about transporting your motorcycle, see page 187 .

| | |
|--|-----|
| General Guidelines..... | 190 |
| If Your Engine Quits or Won't Start .. | 191 |
| If You Have a Flat Tire..... | 196 |
| If Your Engine Overheats..... | 210 |
| If the Low Oil Pressure Indicator | |
| Lights..... | 212 |
| If a Fuse Blows..... | 213 |
| If You Crash..... | 220 |
| If You Lose Your Key..... | 221 |
| If Your Battery Is Low (or Dead)..... | 222 |