









INFO 2

You can select the "REV", "INST.CON.S.", "AVG.CON.S.", "TRIP A CON.S.", "AVG.SPD." or "ELAPSED" for INFO 2.

- 1 Select the "INFO 2" using the **SEL**  (up) or **SEL**  (down) button, and press the **MODE** button.
 - u Press and hold the **SEL**  (up) or **SEL**  (down) button to move the menu quickly.

12:34		SETTING	0 km/h
FUNCTION	BACKGROUND		
LAP TIME	USER LETTER		INFO 1
DISPLAY FAVORITE			INFO 2
GENERAL			INFO 3
SERVICE	DISPLAY MODE		

- 2 Select the "REV", "INST.CON.S.", "AVG.CON.S.", "TRIP A CON.S.", "AVG.SPD." or "ELAPSED" using the **SEL**  (up) or **SEL**  (down) button.
 - u Press and hold the **SEL**  (up) or **SEL**  (down) button to move the menu quickly.

12:34		SETTING	0 mph
FUNCTION	BACKGROUND		AVG.SPD.
LAP TIME	USER LETTER		ELAPSED
DISPLAY FAVORITE			REV
GENERAL			INST.CON.S.
SERVICE	DISPLAY MODE		AVG.CON.S.

- 3 Press the **MODE** button. The "INFO 2" setting is set, and then the display returns to the upper level hierarchy.