


Instruments (Continued)

To Measure the Lap Time

- 1 Press and hold the **[LAP]** button or select the "CIRCUIT" menu on the "DISPLAY MODE" menu screen. **➡P.24** **➡P.58** **➡P.59**
- 2 To start measuring, press the **[LAP]** button.
 - u The stopwatch starts measuring.



- 3 To record lap time, press the **[LAP]** button at each lap.
 - u The stopwatch changes to display the difference with the best lap. After 10 seconds, the display will return to the stopwatch.
 - u The previous lap time and previous lap number change to the information of the previous lap.
 - u If you press the **[LAP]** button again within two seconds, lap time is not recorded.
 - u When exceeds 50 lap, the previous lap number repeats the "LAP 50."