

Switches

LAP button

Operate the lap timer



Horn button



Turn signal switch


u Pressing the switch turns the turn signal off.






Hazard switch

Switchable when the ignition switch is on. Can be turned to off regardless of the ignition switch position.

u The signals continue flashing with the ignition switch is OFF or LOCK after the hazard switch is on.



Headlight dimmer switch/Passing light control switch

-  : High beam
-  : Low beam
-  **PASS** : Flashes the high beam headlight.