


Instruments *(Continued)*

- e Press the **3** (up) button or the **4** (down) button until the desired minute is displayed.
- u Press and hold the **3** (up) button or the **4** (down) button to advance the minute fast.




- ! Press the **SET** button. The clock is set, and then the display moves to the backlight brightness adjustment.

2 Backlight brightness adjustment:

You can adjust the brightness to one of five levels.

- a Press the **3** (up) button or the **4** (down) button. The brightness is switched.



→ Press the **3** (up) button

⇐ Press the **4** (down) button

- b Press the **SET** button. The backlight is set, and then the display moves to the changing of the speed and mileage unit.