

## Instruments *(Continued)*

- 5 Press the ▲ (up) button or the ▼ (down) button until the desired minute is displayed.
- u Press and hold the ▲ (up) button or the ▼ (down) button to advance the minute fast.




- 6 Press the SET button. The clock is set, and then the display moves to the backlight brightness adjustment.

## 2 Backlight brightness adjustment:

You can adjust the brightness to one of five levels.

- 1 Press the ▲ (up) button or the ▼ (down) button. The brightness is switched.



→ Press the ▲ (up) button

⇌ Press the ▼ (down) button

- 2 Press the SET button. The backlight is set, and then the display moves to the changing of the speed and mileage unit.